


Hole "A" and "B" are concentric

after adjusting


Adjusting the B slat support with

straight screwdriver as oicture shown.




Spare parts list

Label No.	Part description	Drawing	Qty
A1	Column I		2
A2	Column I		2
B1	Beam (Left)	<u> </u>	1
B2	Beam(Right)	:	1
С	Front and rear beams		2
D	Middle beam	[1
E	Slat		3x3=44 3x4=60 4x4=60
F	Column bottom plate		4
G	Column cover plate		4
Н	Connectors for middle beams		2
I	Hinge ring		2
J	Hand crank		2







1. The following image shows how to insert plastic jam into foremost slat.



2.Turn on the slat to half position, insert the plastic jam N into hole of two ends of each slat in turn.

Label No.	Part description	Drawing	Qty
K1	Countersunk head screw	M6x16	40+2
K2	Pan head screw	M6x16	20+2
K3	Flat washer	D6x12	8+2
K4	Screw+nut	M4x25	2
L	Woodworking screw+ plastic expansion pipe +Flat washer	M8x80 Ø 8	16
М	Glass glue		1
N	Plastic jam		3x3=88 3x4=120 4x4=120
0	Corner support		8
K5	Self-drilling screw ST 4.2x25	ST4.2x25	32





13. Insert 6pcs slat (E) first (4pieces at gear box side and 2pcs at other side) on the end of the brackets on both sides of the beams (B1-D and B2-D), and press down on the slat as shown in the sketch below to secure it.

