

## ELECTRIC FAN HEATER

### Instructions for safety and use

The electric fan heater is intended for drying walls and floors. The efficiency increases in combination with the use of a dehumidifier. The electric fan heater produces clean, dry and hot or cold air. The electric fan heater is also suitable for heating and ventilating offices, sheds, workshops and small party tents.



## SAFETY INSTRUCTIONS



### Please

Read this manual and the additional safety instructions carefully to get the most out of your new electric fan heater.

- The fan heater is not suitable for outdoor use in humid weather, in bathrooms or in other humid environments.
- Please note that the electric fan heater can BECOME VERY HOT. Therefore, do not place the fan heater near flammable products such as furniture, curtains, gas cylinders, etc
- DO NOT cover the fan heater during use or shortly thereafter.
- Do not place the fan heater immediately under an electrical outlet.
- Do not use the fan heater in conjunction with a timer / switching clock or similar equipment, which can automatically turn on.
- Do not place the fan heater in a room where flammable gases or liquids are used and / or stored.
- If an extension cable is used, keep it short and always fully unroll the cable.

## 1. OPERATING FUNCTIONS



- Temperature regulator
- Function selection dial

## 2. DETAILS

- Temperature adjustable : from 0 to 40 ° C
- Minimum required fuse : 16A

## 3. OPERATING

- Place the electric fan heater in such a way that it stands upright on a solid surface. Make sure the fan heater is at a safe distance from moist and / or flammable objects.
- Connect the fan heater to a working electrical outlet.
- Set the temperature control to the maximum position.
- The fan heater will switch on as soon as one of the functions is selected with the function selector dial.
- Once the area has reached the desired temperature, slowly turn the temperature control counterclockwise until the electric fan heater switches off. The electric fan heater will now automatically switch on and off to keep the area at the correct temperature.

**Contact your rental company should you encounter problems with the machine!**

**The product must be returned clean and undamaged.**